


Key Info Guide



The Account Info Screen



Key Info Guide



Enter Vend Code Manually

From Account Info Screen → Menu → Account = Manual Vend Code Screen



How To Top Up

HEAT



1234 1234 1096 1234 123



Any PayPoint Store In The UK



Pay Online @ www.lanten4u.co.uk



Call Us On 0345 4707 222 (min top up £25)

www.lanten4u.co.uk
Get info and make payments online...



www.lanten4u.co.uk

Need to Contact Us? Email support@lanten4u.co.uk